

2L touch-free stainless steel liquid soap dispenser, behind mirror, bottom opening for refilling

Reference: **AS-095**



PRE-INSTALLATION

Read these instructions carefully before installation and retain for future reference.

Remove all packaging and check the contents for damage before beginning installation.

This dispenser is for liquid soap use only.

This liquid soap dispenser is designed for installation in a mirrored cabinet or similar.

This dispenser uses non-rechargeable batteries. Do not mix these batteries with lithium or other types.

Do not mix new and used batteries.


Ensure that the polarity of the + and - batteries is correct to ensure correct operation.

Remove the batteries if the device is not in use or in standby mode for a long period.

Made of stainless steel with internal components made of different materials.

Key-operated lock.

DIMENSIONS




INSTALLATION

STEP 1 - SETTING UP THE SOAP DISPENSER


1

Follow the recommended dimensions to prepare the opening in the base of the cabinet or shelf, then drill 4 pilot holes as shown.






2

Position the dispenser from below.
Open the dispenser with the key to access the mounting frame.
Secure with 4 screws (not included).




INSTALLATION

STEP 2 - BATTERY INSTALLATION

1	Support the base, unlock, and gently open the dispenser. Access the spring and press as shown to release the pump and tank.	
2	Remove the pump cover and replace the batteries as shown.	
3	Once the batteries are inserted, replace the cover and reinsert the tank and the pump mechanism into the dispenser housing. Indicator lights: A blue light indicates the correct battery charge level. If the light is red, replace the batteries.	

STEP 3 - FILLING THE SOAP TANK

1	Support the base, unlock, and gently open the dispenser. Unscrew the tank cover and pour the liquid soap directly into the tank or use the supplied filling hose. Screw the cover back on. If this is the first refill, prime the dispenser by activating the sensor several times until the soap is dispensed.	
-----------------	---	---

MAINTENANCE

The dispenser should not be cleaned with a direct stream of water.

No special tools or accessories are required for the maintenance of this dispenser.

Wipe the stainless steel surfaces with a soft, clean cloth that is slightly damp, then dry with a soft, dry cloth.

Do not use soap, chemical detergents, bleach, or abrasive products.

Periodically, the tank and pump should be removed and cleaned with hot water to remove any buildup of solidified soap.

ATTENTION : When decommissioning your device, contact your local waste disposal service to find the nearest drop-off site. Most of the components can be recycled in accordance with your local recycling regulations. Do not dispose of batteries with household waste.



LIMITED WARRANTY

This recessed behind-mirror soap dispenser includes a 10-year warranty, starting from the date of purchase.

If a defect is found during this period under normal use, you are entitled, at SUPRATECH's discretion, to either a replacement or repair of the defective parts due to material or manufacturing faults.

In no case shall SUPRATECH's liability exceed the purchase price of the product. This warranty does not apply to failures caused by improper installation and maintenance, normal wear and tear, or degradation.

Failure to follow the safety precautions and/or installation recommendations outlined in this installation guide will void the warranty.

For any warranty claims, contact your installer, retailer, or SUPRATECH.

Make sure to provide all relevant information for your claim: a complete description of the malfunction, product reference and serial number, proof of purchase, and installation date.

01.2025