

# SUPRATECH

**HYGIENE ON THE MOVE!**

If necessary, use the (optional) **RES-38** remote control to adjust the soap dispenser's settings. To use the remote control, hold it straight in front of the sensor, at a distance of about 10-15 cm.

**WARNING:** Holding the remote control out of the recommended range (too close or too far) may affect its operation.

Select the function you want to adjust by pressing the corresponding button as follows:

## 1 SOAP DOSAGE

The 1-4 drop keys let the user choose the soap quantity in cm<sup>3</sup>.

① 0.7 to 0.9 \*

② 1.2 to 1.6 \*

③ 1.6 to 1.9 \*

④ 2.1 to 2.3 \*

Indication: continuous blink of the LED in the sensor eye.

\*The exact soap dosage depends on the soap viscosity.

## 2 ADJ

This function resets the soap quantity back to its factory settings.

Indication: 2 blinks of the LED in the sensor eye.

## 3 TEMPORARY OFF FUNCTION

This feature allows activities in front of the sensor without triggering it (e.g., cleaning). Stops for 1 minute.

Either wait 1 minute or press the button again to restart.

Indication: **STOP** = 2 quick flashes

**START** = 4 quick flashes

## 4 RECHARGE SAVON

When the soap reservoir has been refilled, press the **FILL** button.

The pump will operate for 1 minute until soap flows from the spout.

Press the **FILL** button again to stop this activity.



Ref. RES-38